

# IDZOR 9750BT Bluetooth Barcode Scanner Settings



## Basic Introduction

Power On	Press button for 3s then it power on.
Power Off	Scan "Power Off" to shut down, or scan Standby Time to set power off time.
Bluetooth Connection	Refer to Bluetooth Connection Settings. Connected: Scanner: Blue LED flashing. Cradle: Blue LED on.
Low Power Alert	Please charge the scanner when you hear "di-di-di--".
Charging	Put the scanner in the cradle or charge via micro USB interface at the bottom of the scanner.

## System Settings



## Bluetooth Device Input Method




**Note:** Please set input method to English.



## Standby Time



**Note:** Power off if not used within standby time. Scanner will reconnect when power on again.



## Bluetooth Keyboard Transmission Speed



## Bluetooth Connection Settings



Steps:

1. Set BT Cradle According to «Bluetooth Barcode Scanner Instructions».
2. Scan "Connect BT Cradle".
3. Scan Cradle address barcode at the bottom of the Cradle.
4. Wait for connection complete.

**Note :** Scan Bluetooth Connection Settings will empty pairing information.



Steps:

1. Scan "Bluetooth Keyboard mode".
2. Bluetooth device search "SL\_+12 characters".
3. Click to link.

**Note :** Please delete scanner's information on old device before you connect to a new one.



Steps:

1. Scan "Bluetooth GATT mode".
2. Bluetooth device search "SL\_+12 characters".
3. Click to link.

**Note :** Please delete scanner's information on old device before you connect to a new one.

## Transmission Mode




**Note:** Data transmit when Bluetooth connected, drop when disconnected.




**Note:** Data is stored when Bluetooth disconnected and will upload automatically when reconnect.



**Note:** Data is always stored.



## Scanning Mode



## Suffix Setting



## Power Settings

