

CT-5801 Terminal module (Required)

1 Module Description


The terminal module is used to stabilize internal bus communication and it is required. The terminal module CT-5801 has no process data and no configuration parameters.

CT-5801 requires no configuration and occupies no slot in configuration.

2 Technical Parameters

None

3 Hardware Interface



① Module Type

③ Internal Bus

- ④ Buckle
- ⑤ Grounding Resilient Sheet
- ⑥ Terminal Cover

3.1 LED indicator definition

None

A Dimension drawing

